

# Installation, Operation, and Maintenance Manual

8107.011/.030/.300/.590 Maxi





# Table of Contents

<b>Introduction and Safety</b> .....	<b>3</b>
Introduction.....	3
Safety terminology and symbols.....	3
User safety.....	4
Special hazards.....	5
Protecting the environment.....	6
Spare parts.....	6
Warranty.....	6
<b>Transportation and Storage</b> .....	<b>7</b>
Inspect the delivery.....	7
Inspect the package.....	7
Inspect the unit.....	7
Transportation guidelines.....	7
Lifting.....	7
Temperature ranges for transportation, handling and storage.....	7
Storage guidelines.....	8
<b>Product Description</b> .....	<b>9</b>
Products included.....	9
Pump design.....	9
Monitoring equipment.....	10
The data plate.....	10
Approvals.....	11
<b>Installation</b> .....	<b>12</b>
Install the pump.....	12
Install.....	13
Make the electrical connections.....	14
Product-specific precautions.....	16
Prepare the SUBCAB® cables.....	16
Connect the motor cable to the pump: Version code 011/030/300.....	18
Connect the motor cable to the pump: Version code 590.....	20
Cable charts.....	21
Check the impeller rotation: Pumps without built-in motor protection.....	24
Check the phase sequence: Pumps with built-in motor protection.....	25
<b>Operation</b> .....	<b>28</b>
Start the pump.....	28
Clean the pump.....	29
<b>Maintenance</b> .....	<b>30</b>
Torque values.....	31
Service.....	31
Inspection.....	32
Major overhaul.....	33
Change the oil.....	33
Replace the impeller.....	34
Remove the impeller, alternative 1.....	34
Remove the impeller, alternative 2.....	35

Remove the impeller, alternative 3.....	37
Remove the impeller, alternative 4.....	39
Install the impeller, alternative 1.....	41
Install the impeller, alternative 2.....	42
Install the impeller, alternative 3.....	45
Install the impeller, alternative 4.....	51
Adjust the impeller.....	53
Replace the diffuser.....	54
<b>Troubleshooting.....</b>	<b>56</b>
The pump does not start.....	56
The pump does not start, for pumps with SMART™.....	58
The pump does not stop when a level sensor is used.....	58
The pump starts-stops-starts in rapid sequence.....	59
The pump runs but the motor protection trips.....	59
The pump delivers too little or no water.....	60
<b>Technical Reference.....</b>	<b>62</b>
Application limits.....	62
Motor data.....	62
Specific motor data: Version code .011/.030/.300.....	62
Specific motor data: Version code .590.....	66
Dimensions and weights.....	66
8107.011 SH.....	66
8107.011 H and 8107.300 H.....	67
8107.011 N and 8107.030 L.....	67
8107.590 H.....	68
Performance curves.....	68
8107.011 SH.....	69
8107.011 N, H: Open impeller.....	69
8107.300 H: Open impeller.....	70
8107.030 L.....	71
8107.590 H.....	72

# Introduction and Safety

## Introduction

### Purpose of the manual

The purpose of this manual is to provide necessary information for working with the unit. Read this manual carefully before starting work.

### Read and keep the manual

Save this manual for future reference, and keep it readily available at the location of the unit.

### Intended use



#### **WARNING:**

Operating, installing, or maintaining the unit in any way that is not covered in this manual could cause death, serious personal injury, or damage to the equipment and the surroundings. This includes any modification to the equipment or use of parts not provided by Grindex. If there is a question regarding the intended use of the equipment, please contact a Grindex representative before proceeding.

### Other manuals

See also the safety requirements and information in the original manufacturer's manuals for any other equipment furnished separately for use in this system.




## Safety terminology and symbols

### About safety messages

It is extremely important that you read, understand, and follow the safety messages and regulations carefully before handling the product. They are published to help prevent these hazards:

- Personal accidents and health problems
- Damage to the product and its surroundings
- Product malfunction



### Hazard levels

Hazard level	Indication
 <b>DANGER:</b>	A hazardous situation which, if not avoided, will result in death or serious injury
 <b>WARNING:</b>	A hazardous situation which, if not avoided, could result in death or serious injury
 <b>CAUTION:</b>	A hazardous situation which, if not avoided, could result in minor or moderate injury

Hazard level	Indication
<b>NOTICE:</b>	Notices are used when there is a risk of equipment damage or decreased performance, but not personal injury.

**Special symbols**

Some hazard categories have specific symbols, as shown in the following table.

Electrical hazard	Magnetic fields hazard
 <p><b>Electrical Hazard:</b></p>	 <p><b>CAUTION:</b></p>

**User safety**

All regulations, codes, and health and safety directives must be observed.

**The site**

- Observe lockout/tagout procedures before starting work on the product, such as transportation, installation, maintenance, or service.
- Pay attention to the risks presented by gas and vapors in the work area.
- Always be aware of the area surrounding the equipment, and any hazards posed by the site or nearby equipment.

**Qualified personnel**

This product must be installed, operated, and maintained by qualified personnel only.


**Protective equipment and safety devices**

- Use personal protective equipment as needed. Examples of personal protective equipment include, but are not limited to, hard hats, safety goggles, protective gloves and shoes, and breathing equipment.
- Make sure that all safety features on the product are functioning and in use at all times when the unit is being operated.

**MSHA requirements**

According to the United States of America's Code of Federal Regulations, the following requirements must be fulfilled to maintain Mine Safety and Health Administration (MSHA) permissibility of this equipment:

Subject area	Requirements
General safety	<ul style="list-style-type: none"> <li>• Frequent inspections must be made.</li> <li>• All electrical parts, portable cable, and wiring must be kept in a safe condition.</li> <li>• There must not be any openings into the casings of the electrical parts.</li> <li>• The machine frame must be effectively grounded (earthed).</li> <li>• Power wires must not be used for grounding (earthing) .</li> <li>• The operating voltage must match the voltage rating of the motor.</li> </ul>

Subject area	Requirements
Service and repair	<ul style="list-style-type: none"> <li>• Inspections, service, and repairs are only allowed when the portable cable is disconnected from the power supply.</li> <li>• Work must be performed by trained personnel (preferably the manufacturer or agent) to ensure that the pump is restored to its original state of safety in regards to all flame-arresting paths.</li> <li>• Replacement parts must be exactly equal to those provided by the manufacturer.</li> <li>• When cable entries are disturbed on pump or control, they must be reassembled in the approved manner.</li> </ul> <div style="display: flex; align-items: center; margin-top: 10px;">  <div style="border-top: 1px solid black; padding-top: 5px;"> <p><b>CAUTION: Explosion/Fire Hazard</b></p> <p>Failure to restore the permissible equipment to its original state of safety will void the MSHA approval. The creation of a safety hazard will subject the owner / operator of a mine to citations and penalties under the law.</p> </div> </div>
Fastenings	All bolts, nuts, screws, and threaded covers must be properly tightened and secured.
Cables	A flame-resistant portable cable must be used. It has to bear an MSHA-assigned identification number and be adequately protected by an automatic circuit-interrupting device. Special care must be taken in handling the cable to avoid mechanical damage and wear.
Operation	Polyurethane-equipped products must not be operated dry in hazardous areas.

## Special hazards

### Working in temporary installations

Certain industries, such as mining or construction, have a dynamic nature and require temporary installation of equipment. Due to the rugged nature of these applications, normal use of electrical equipment causes wear and tear that can result in insulation breaks, short-circuits, and exposed wires. To maximize safety when using the unit in rugged applications, the following conditions must be met:

- If electrical cables must be located such that they are at risk of being run over by heavy equipment, then provide mechanical protection to prevent physical damage to the cables.
- Visually inspect electrical equipment before use. Remove from service any equipment with exposed wires or visible damage.
- Use ground-fault circuit interrupters on all receptacles, or have an assured equipment grounding conductor program.

### Biological hazards

The product is designed for use in liquids that can be hazardous to your health. Observe these rules when you work with the product:

- Make sure that all personnel who may come into contact with biological hazards are vaccinated against diseases to which they may be exposed.
- Observe strict personal cleanliness.



---

**WARNING: Biological Hazard**

Infection risk. Rinse the unit thoroughly with clean water before working on it.

---

**Wash the skin and eyes**

Follow these procedures for chemicals or hazardous fluids that have come into contact with your eyes or your skin:

Condition	Action
Chemicals or hazardous fluids in eyes	<ol style="list-style-type: none"><li>1. Hold your eyelids apart forcibly with your fingers.</li><li>2. Rinse the eyes with eyewash or running water for at least 15 minutes.</li><li>3. Seek medical attention.</li></ol>
Chemicals or hazardous fluids on skin	<ol style="list-style-type: none"><li>1. Remove contaminated clothing.</li><li>2. Wash the skin with soap and water for at least 1 minute.</li><li>3. Seek medical attention, if necessary.</li></ol>

**Protecting the environment**

**Emissions and waste disposal**

Observe the local regulations and codes regarding:

- Reporting of emissions to the appropriate authorities
- Sorting, recycling and disposal of solid or liquid waste
- Clean-up of spills

**Exceptional sites**



---

**CAUTION: Radiation Hazard**

Do NOT send the product to Grindex if it has been exposed to nuclear radiation, unless Grindex has been informed and appropriate actions have been agreed upon.

---

**Spare parts**



---

**CAUTION:**

Only use the manufacturer's original spare parts to replace any worn or faulty components. The use of unsuitable spare parts may cause malfunctions, damage, and injuries as well as void the warranty.

---

**Warranty**

For information about warranty, see the sales contract.



# Transportation and Storage

## Inspect the delivery

### Inspect the package

1. Inspect the package for damaged or missing items upon delivery.
2. Note any damaged or missing items on the receipt and freight bill.
3. File a claim with the shipping company if anything is out of order.  
If the product has been picked up at a distributor, make a claim directly to the distributor.

### Inspect the unit

1. Remove packing materials from the product.  
Dispose of all packing materials in accordance with local regulations.
2. Inspect the product to determine if any parts have been damaged or are missing.
3. If applicable, unfasten the product by removing any screws, bolts, or straps.  
For your personal safety, be careful when you handle nails and straps.
4. Contact the local sales representative if there is any issue.

## Transportation guidelines

### Precautions




---

#### **DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

---

### Position and fastening

The unit can be transported either horizontally or vertically. Make sure that the unit is securely fastened during transportation, and cannot roll or fall over.

### Lifting



Always inspect the lifting equipment and tackle before starting any work.

---

#### **WARNING: Crush Hazard**

1) Always lift the unit by its designated lifting points. 2) Use suitable lifting equipment and ensure that the product is properly harnessed. 3) Wear personal protective equipment. 4) Stay clear of cables and suspended loads.

---

#### **NOTICE:**

Never lift the unit by its cables or hose.

---

## Temperature ranges for transportation, handling and storage

### Handling at freezing temperature

At temperatures below freezing, the product and all installation equipment, including the lifting gear, must be handled with extreme care.

Make sure that the product is warmed up to a temperature above the freezing point before starting up. Avoid rotating the impeller/propeller by hand at

temperatures below the freezing point. The recommended method to warm the unit up is to submerge it in the liquid which will be pumped or mixed.

---

**NOTICE:**

Never use a naked flame to thaw the unit.

---

**Unit in as-delivered condition**

If the unit is still in the condition in which it left the factory - all packing materials are undisturbed - then the acceptable temperature range during transportation, handling and storage is:  $-50^{\circ}\text{C}$  ( $-58^{\circ}\text{F}$ ) to  $+60^{\circ}\text{C}$  ( $+140^{\circ}\text{F}$ ).

If the unit has been exposed to freezing temperatures, then allow it to reach the ambient temperature of the sump before operating.

**Lifting the unit out of liquid**

The unit is normally protected from freezing while operating or immersed in liquid, but the impeller/propeller and the shaft seal may freeze if the unit is lifted out of the liquid into a surrounding temperature below freezing.

Units equipped with an internal cooling system are filled with a mixture of water and 30% glycol. This mixture remains a flowing liquid at temperatures down to  $-13^{\circ}\text{C}$  ( $9^{\circ}\text{F}$ ). Below  $-13^{\circ}\text{C}$  ( $9^{\circ}\text{F}$ ), the viscosity increases such that the glycol mixture will lose its flow properties. However, the glycol-water mixture will not solidify completely and thus cannot harm the product.

Follow these guidelines to avoid freezing damage:

1. Empty all pumped liquid, if applicable.
2. Check all liquids used for lubrication or cooling, both oil and water-glycol mixtures, for the presence of unacceptable amounts of water. Change if needed.

## Storage guidelines

**Storage location**

The product must be stored in a covered and dry location free from heat, dirt, and vibrations.

---

**NOTICE:**

Protect the product against humidity, heat sources, and mechanical damage.

---

**NOTICE:**

Do not place heavy weights on the packed product.

---

**Long-term storage**

If the unit is stored more than six months, then the following apply:

- Before operating the unit after storage, it must be inspected with special attention to the seals and the cable entry.
- The impeller/propeller must be rotated every other month to prevent the seals from sticking together.

# Product Description

## Products included

Pump model	Standard	EX	MSHA	Drainage	Sludge
Maxi 8107.011	X			X	
Maxi 8107.030	X			X	
Maxi Lite 8107.300	X			X	
Maxi 8107.590			X	X	

## Pump design

The pump is submersible, and driven by an electric motor.

### Intended use

The product is intended for moving waste water, sludge, raw and clean water. Always follow the limits given in [Application limits](#) on page 62. If there is a question regarding the intended use of the equipment, please contact a Grindex representative before proceeding.



### **DANGER: Explosion/Fire Hazard**

Special rules apply to installations in explosive or flammable atmospheres. Do not install the product or any auxiliary equipment in an explosive zone unless it is rated explosion-proof or intrinsically-safe. If the product is EN/ATEX-, MSHA- or FM-approved, then see the specific EX information in the Safety chapter before taking any further actions.

### **NOTICE:**

Do NOT use the unit in highly corrosive liquids.

For information about pH, see [Application limits](#) on page 62.

### Particle size

The pump can handle liquid containing particles that correspond to the holes in the strainer.

Product version	Number of holes	Hole dimensions
011 H/SH 300 590	541	Diameter 12 mm (0.47 in)
011 N 030	630	Diameter 15 mm (0.59 in)

### Pressure class

L	Low head
N	Medium head
H	High head
SH	Super head

### Impeller type

Wear resistant

### Poly-Life®

Version code 011/030/300: The pump is available with polyurethane wear parts for extra resistance.

## Monitoring equipment

The following applies to the monitoring equipment of the pump:

- The stator incorporates thermal contacts connected in series that activate the alarm at overtemperature.
- The thermal contacts open and close at the following temperatures:


Pump	Thermal contacts open	Thermal contacts close
8107.300	140°C (284°F)	105°C (221°F)
8107.011, 8107.030, 8107.590	125°C (257°F)	90°C (194°F)

## The data plate

### Introduction

The data plate is a metal label located on the main body of the pump. The data plate lists key product specifications.

### The data plate




1. Pump type number
2. Frequency
3. Phases, type of current
4. Rated shaft power
5. Thermal class
6. Locked rotor code-letter
7. Country of origin
8. Maximum power consumption
9. Product weight
10. Maximum submersion depth
11. Degree of protection
12. Maximum capacity
13. Rated current
14. Direction of the start reaction
15. Direction of the impeller rotation
16. Maximum head
17. Serial number
18. Rated voltage
19. Pump model

## Approvals

### Product approvals for hazardous locations

Pump model	Approvals
Maxi 8107.590	MSHA: Mine Safety and Health Administration, USA. 30CFR Part 7, Approval number 07-JA090015-0

### The MSHA approval plate



# Installation

## Install the pump

Before starting work, make sure that the safety instructions in the chapter *Introduction and Safety* on page 3 have been read and understood.



### **DANGER: Electrical Hazard**

Before starting work on the unit, make sure that the unit and the control panel are isolated from the power supply and cannot be energized. This applies to the control circuit as well.



### **DANGER: Inhalation Hazard**

Before entering the work area, make sure that the atmosphere contains sufficient oxygen and no toxic gases.

## Hazardous atmospheres



### **DANGER: Explosion/Fire Hazard**

Special rules apply to installations in explosive or flammable atmospheres. Do not install the product or any auxiliary equipment in an explosive zone unless it is rated explosion-proof or intrinsically-safe. If the product is EN/ATEX-, MSHA- or FM-approved, then see the specific EX information in the Safety chapter before taking any further actions.



### **WARNING: Explosion/Fire Hazard**

Do not install CSA-approved products in locations that are classified as hazardous in the National Electric Code(TM), ANSI/NFPA 70-2005.

## Authority regulation

Vent the tank of a sewage station in accordance with local plumbing codes.

## Sedimentation prevention

In order to avoid sedimentation when the pumped liquid contains solid particles, the velocity of the liquid in the discharge line must exceed a certain value. Choose applicable minimum velocity from the table, and choose proper dimension of the discharge line accordingly.

Mixture	Minimum velocity, meter per second (feet per second)
Water + coarse gravel	4 (13)
Water + gravel	3.5 (11)
Water + sand, particle size <0.6 mm (0.024 in)	2.5 (8.2)
Water + sand, particle size <0.1 mm (0.004 in)	1.5 (4.9)

For more permanent installations with a heavily contaminated pumped liquid, a settling pump-sump is recommended.





Figure 1: Settling pump-sump

**Discharge line requirements**

The discharge line can be run vertically or horizontally, but must be without sharp bends.



**Fasteners**

- Only use fasteners of the proper size and material.
- Replace all corroded fasteners.
- Make sure that all fasteners are properly tightened and that there are no missing fasteners.

**Install**

The pump is transportable and intended to operate either completely or partially submerged in the pumped liquid. The pump is equipped with a connection for hose or pipe.

These requirements and instructions only apply when the installation is made according to the dimensional drawing.

1. Run the cable so that it has no sharp bends, is not pinched, and cannot be sucked into the pump inlet.
2. Connect the discharge line.

The discharge line can be run vertically or horizontally, but must be without sharp bends.

3. Lower the pump into the sump.

The cable must not be used for this purpose. You should attach a rope or similar to the handle or the eye bolts for lowering and lifting the pump.

Heavier pumps must be lifted and lowered down by crane. Suspend the pump by the lifting handle or the eye bolts with chains or wires.

4. Place the pump on the base and make sure it cannot fall over or sink.  
 The base should consist of a plank, a bed of coarse gravel, or a cut-down and perforated oil drum.  
 Alternatively, the pump can be suspended with a lifting chain just above the sump bottom. Make sure that the pump cannot rotate at start-up or during operation.
5. Connect the motor cable and the starter and monitoring equipment according to the separate instructions.  
 Maxi MSHA: Make sure that the impeller rotation is correct. For more information, see [Check the impeller rotation: Pumps without built-in motor protection](#) on page 24.  
 Maxi: Make sure that the phase sequence is correct. For more information, see [Check the phase sequence: Pumps with built-in motor protection](#) on page 25.

## Make the electrical connections


### General precautions




---

#### **DANGER: Electrical Hazard**

Before starting work on the unit, make sure that the unit and the control panel are isolated from the power supply and cannot be energized. This applies to the control circuit as well.




---

#### **WARNING: Electrical Hazard**

Risk of electrical shock or burn. A certified electrician must supervise all electrical work. Comply with all local codes and regulations.




---

#### **WARNING: Electrical Hazard**

There is a risk of electrical shock or explosion if the electrical connections are not correctly carried out, or if there is fault or damage on the product. Visually inspect equipment for damaged cables, cracked casings or other signs of damage. Make sure that electrical connections have been correctly made.




---

#### **WARNING: Crush Hazard**

Risk of automatic restart.




---

#### **CAUTION: Electrical Hazard**

Prevent cables from becoming sharply bent or damaged.

---

#### **NOTICE:**

Leakage into the electrical parts can cause damaged equipment or a blown fuse. Keep the cable ends dry at all times.

### Requirements

These general requirements apply for electrical installation:



- The supply authority must be notified before installing the pump if it will be connected to the public mains. When the pump is connected to the public power supply, it may cause flickering of incandescent lamps when started.
- The mains voltage and frequency must agree with the specifications on the data plate. If the pump can be connected to different voltages, then the connected voltage is specified by a yellow sticker close to the cable entry.
- The fuses and circuit breakers must have the proper rating, and the pump overload protection (motor protection breaker) must be connected and set to the rated current according to the data plate and if applicable the cable chart. The starting current in direct-on-line start can be up to six times higher than the rated current.
- The fuse rating and the cables must be in accordance with the local rules and regulations.
- If intermittent operation is prescribed, then the pump must be provided with monitoring equipment supporting such operation.
- The thermal contacts/thermistors must be in use.

## Cables

These are the requirements to follow when you install cables:

- The cables must be in good condition, not have any sharp bends, and not be pinched.
- The cables must not be damaged and must not have indentations or be embossed (with markings, etc.) at the cable entry.
- The cable entry seal sleeve and washers must conform to the outside diameter of the cable.
- The minimum bending radius must not be below the accepted value.
- If using a cable which has been used before, a short piece must be peeled off when refitting it so that the cable entry seal sleeve does not close around the cable at the same point again. If the outer sheath of the cable is damaged, then replace the cable. Contact a Grindex service shop.
- The voltage drop in long cables must be taken into account. The drive unit's rated voltage is the voltage measured at the cable connection point in the pump.
- For SUBCAB<sup>®</sup> cables, the twisted pair copper foil must be trimmed.
- All unused conductors must be insulated.

## Grounding (earthing)

Grounding (earthing) must be done in compliance with all local codes and regulations.



### **DANGER: Electrical Hazard**

All electrical equipment must be grounded (earthed). Test the ground (earth) lead to verify that it is connected correctly. Frequently inspect electrical systems to ensure that the path to ground is continuous.



### **WARNING: Electrical Hazard**

If the power cable is jerked loose, then the ground (earth) conductor must be the last conductor to come loose from its terminal. Make sure that the ground (earth) conductor is longer than the phase conductors at both ends of the cable.



### **WARNING: Electrical Hazard**

Risk of electrical shock or burn. You must connect an additional ground- (earth-) fault protection device to the grounded (earthed) connectors if persons are likely to come into contact with liquids that are also in contact with the pump or pumped liquid.

**Ground (earth) conductor length**

The ground (earth) conductor must be 100 mm (4.0 in) longer than the phase conductors in the junction box of the unit.

**Product-specific precautions**

**Short-circuit protection**

The short-circuit protection should be in accordance with the rated data shown on the data plate. Use time-delay fuses rated  $1.5 \times$  the rated current for the actual pump.

**Pumps without built-in motor protection**

The following requirements apply:

- The thermal overload circuit breaker/relay must conform to the rated current and motor power input of the actual pump. The overload relay should be set as follows:

Start option	Overload relay setting
DOL start	$1.1 \times$ the rated current (line current)
Y/D start	$0.58 \times$ the rated current (phase current)

- The pump must be equipped with an external motor starter with a protection system. Use any of the following alternatives:
  - On/off switch, thermal overload magnetic circuit breaker/relay, and integrated thermal monitoring system (for connection of motor thermal contacts circuit T1/T2)
  - On/off switch and thermal overload circuit breaker/relay

**Connection of the pump to a local power source**

The following recommendations apply:

- Make sure that the local power source can start and run the actual pump. The following maximum power kVA values for the generator are recommended:

**Table 1: DOL start**

Number of pumps driven by the same generator	Recommended maximum power kVA values for the generator, as a multiple $\times$ the maximum power consumption for one pump
1	3
2	4.5



**Table 2: Y/D start**

Number of pumps driven by the same generator	Recommended maximum power kVA values for the generator, as a multiple $\times$ the maximum power consumption for one pump
1	2.3
2	3.4


- Consult the generator manufacturer about the generator capabilities.
- Do not use the Generator set Auto idle function.

**Prepare the SUBCAB<sup>®</sup> cables**

This section applies to SUBCAB<sup>®</sup> cables with twisted-pair control cores.

The prepared SUBCAB® cable	The prepared screened SUBCAB® cable
 <p>1. T1+T2 twisted pairs in control element  2. Drain wire in control element (bare copper wire)  3. Screened copper pt-foil  4. Insulation sheath (jacket) or PT-foil for control element  5. Power cores  6. Ground (earth) core</p> <p style="text-align: right;">WS004299E</p>	 <p>1. T1+T2 and T3+T4 twisted pairs in control element  2. Drain wire in control element (bare copper wire)  3. Screened copper pt-foil  4. Insulation sheath (jacket) for control element  5. Power cores  6. Aluminum foil  7. Ground (earth) core with green/yellow shrink hose  8. Uncovered screen/braided wire</p> <p style="text-align: right;">WS004298C</p>

1. Peel off the outer sheath at the end of the cable.
2. Prepare the control element:
  - a) Peel the sheath (if applicable) and the copper foil.  
The copper foil is a screen and is conductive. Do not peel more than necessary, and remove the peeled foil.



**Figure 2: Copper foil on control element.**


- b) Put a white shrink hose over the drain wire and the cable terminal.
  - c) Fit a cable lug on the drain wire.
  - d) Twist T1+T2 and T3+T4.
  - e) Put a shrink hose over the control element.  
Make sure that the conductive copper foil and drain wire is covered.
3. Prepare the ground (earth) core for SUBCAB™ cable:
  - a) Peel the yellow-green insulation from the ground (earth) core.
  - b) Check that the ground (earth) core is at least 10% longer than the phase cores in the cabinet.
  - c) If applicable, put a cable lug on the ground core.
4. Prepare the ground (earth) core for screened SUBCAB™ cable:
  - a) Untwist the screens around the power cores.
  - b) Put a yellow-green shrink hose over the ground (earth) core.  
Leave a short piece uncovered.
  - c) If applicable, put a cable lug on the screened ground core.

- d) Twist all power core screens together to create a ground (earth) core and fit a cable terminal to the end.
  - e) Check that the ground (earth) core is at least 10% longer than the phase cores in the cabinet.
5. How is the connection to ground (earth) made?
- Screw: Fit cable terminals to the ground (earth) core and the power cores.
  - Terminal block: Leave the core ends as they are.
6. Prepare the main leads:
- a) Remove the aluminum foil around each power core.
  - b) Peel the insulation from each power core.

### Connect the motor cable to the pump: Version code 011/030/300


**NOTICE:**

Leakage into the electrical parts can cause damaged equipment or a blown fuse. Keep the end of the motor cable dry at all times.



Part	Description
1	Screws
2	Entrance flange

Figure 3: Cable entry for version code 011 H and 300 H



Part	Description
1	Screws
2	Entrance flange

**Figure 4: Cable entry for version code 011 N and 030 L**

1. Check the data plate to see which connections are required for the power supply:
  - Y
  - D
  - Y serial
  - Y parallel
  - Y/D
2. Arrange the connections on the terminal board in accordance with the required power supply.  
Do not use links (jumper strips) with the Y/D start.  
Do not use links (jumper strips) with the 9 stator leads tandem-coupling.
3. Connect the motor conductors (U1, V1, W1) to the terminal board. Connect the ground (earth) lead.
4. Make sure that the pump is correctly connected to ground (earth).
5. Make sure that any thermal contacts incorporated in the pump are properly connected to the terminal board.
6. Install the cover.
7. Fasten the screws on the entrance flange so that the cable insertion assembly bottoms out.

After you have connected the motor cable to the pump, connect the motor cable and the control cable to the starter equipment.




---


**DANGER: Explosion/Fire Hazard**

Special rules apply to installations in explosive or flammable atmospheres. Do not install the product or any auxiliary equipment in an explosive zone unless it is rated explosion-proof or intrinsically-safe. If the product is EN/ATEX-, MSHA- or FM-approved, then see the specific EX information in the Safety chapter before taking any further actions.


---

Three thermal contacts are incorporated in the stator. They are normally closed. Thermal contacts must never be exposed to voltages higher than 250 V, breaking current maximum 6 A at a power factor 0.6. It is recommended that the thermal contacts are connected to 24 V over a separate fuse to protect any other automatic equipment.

## Connect the motor cable to the pump: Version code 590



WS002804C



WS008620A

Position number	Description
5	Hexagon head screw
90	Cable entry
92	Gland flange
93	Seal sleeve

Position number	Description
1	Minimum clearance 3.2 mm (0.13 in)
2	Cable strain relief


**Figure 5: Cable entry**

**Figure 6: Cable strain relief**

1. Insert the motor cable.  
25–30 mm (0.9–1.2 in) of the jacket must be on the inside of the cover.
2. Check that the seal sleeves and washers conform to the outside diameter of the cable.
3. Tighten the cable entry so that the seal sleeve is compressed and seals between the motor cable and the cover.  
Leave a clearance between the cover and the flange on the cable entry. See [Figure 6: Cable strain relief](#) on page 20.  
The cable entry is threaded with Pg42/Pr54.
4. Fit the gland flange:
  - a) Fit it with the largest diameter of the hole facing the inside of the cover.
  - b) Tighten the screws, but leave 1 mm (0.04 in) of clearance between the cover and the gland flange.
5. Fit the O-ring on the cover.
6. Connect the leads.
7. Fit and tighten the cover.  
Check, through the inspection hole, that no leads are pinched.
8. Fit the O-ring on the inspection cover.
9. Fit and tighten the inspection cover.
10. Fit and tighten the cable strain relief on the cable entry.

## Cable charts

### Connection locations



1	Starter equipment and main leads (L1, L2, L3)	13	Coil
2	Ground (earth)	14	Transformer
3	Functional ground	15	Capacitor
4	Control leads (T1, T2, T3, T4)	16	Softstarter
5	Phase shifter	17	Level regulator
6	Diode	18	Contactor, start relay or thermal relay
7	Motor cable	19	Thermal detector in stator
8	Screen	20	Thermal detector in main bearing
9	Pump	21	Jumper
10	Crimp connection	22	Terminal board, terminal plate
11	Crimp isolation	23	Leakage sensor
12	Motor protector	24	Stator leads (U1, U2, U5, U6, V1, V2, V5, V6, W1, W2, W5, W6, Z1, Z5, Z6)





### Color code standard

Code	Description
BN	Brown
BK	Black
WH	White
OG	Orange

<b>Code</b>	<b>Description</b>
GN	Green
GNYE	Green-Yellow
RD	Red
GY	Grey
BU	Blue
YE	Yellow



View of terminal board and sensor connections



WS008991A

## Motor cable, stator leads and thermal contacts connection to terminal board

775 13 03.1




8107  
8108  
8124

51 675 01

**SYMBOLS AND DENOMINATIONS**

BN=Brown	⊖=Terminal
BK=Black	⊕=Screen
WH=White	⊕=Ground
OG=Orange	⚡=Functional ground
GN=Green	⚡=Connection
GNYE=Green-Yellow	⚡=Crimp isolation
RD=Red	
GY=Grey	
BU=Blue	
YE=Yellow	

GC= Ground check  
A = Cable dimension in cable specification



WS008992A

## Check the impeller rotation: Pumps without built-in motor protection

Follow this procedure if your product does not have the rotation control SMART™.




---

**CAUTION: Crush Hazard**


The starting jerk can be powerful. Make sure nobody is close to the unit when it is started.

---

Check the direction of rotation each time the cable has been re-connected and after phase or total supply failure.

1. Start the motor.
2. Stop the motor.
3. Check that the impeller rotates in the correct direction.

The correct direction of impeller rotation is clockwise when you look at the pump from above. When started, the pump will react in the opposite direction to the impeller rotation.



**Figure 7: Start reaction**

4. If the impeller rotates in the wrong direction, then do the following:
  - If the motor has a 3-phase connection, then transpose two phase conductors and repeat this procedure from step 1.

For 3-phase pumps with external starters or without built-in motor protection, the phases must be shifted on the output terminal of the starter.

## Check the phase sequence: Pumps with built-in motor protection

Follow this procedure if your product is equipped with the rotation control SMART™.





---

**CAUTION: Crush Hazard**

The starting jerk can be powerful. Make sure nobody is close to the unit when it is started.



---

The correct direction of impeller rotation is clockwise when you look at the pump from above. When started, the pump will react in the opposite direction to the impeller rotation.





**Figure 8: Start reaction**

1. Connect the pump to power as follows:

Condition	Action
The pump has a CEE plug with internal phase shifter.	Connect the plug.  WS006205A
The pump has a phase shifter with an on/off switch.	Turn the knob on the phase shifter in either direction.  WS006207A
The pump has neither a CEE plug with internal phase shifter, nor a phase shifter with an on/off switch.	1. Connect the pump to power. 2. Switch on the power.

The pump should start. If it does not, then continue to the next step.

2. If the pump does not start and the fuses are correct, then shift two phases:

Condition	Action
The pump has a CEE plug with internal phase shifter.	<ol style="list-style-type: none"> <li>1. Pull out the plug.</li> <li>2. Shift two phases.</li> <li>3. Wait until the motor has stopped.</li> <li>4. Connect the plug.</li> </ol>  <p style="text-align: right; font-size: small;">WS006206A</p>
The pump has a phase shifter with an on/off switch.	<ol style="list-style-type: none"> <li>1. Turn the knob on the phase shifter to neutral position.</li> <li>2. Wait until the motor has stopped.</li> <li>3. Turn the knob to the opposite position from before.</li> </ol>  <p style="text-align: right; font-size: small;">WS006208A</p>
The pump has neither a CEE plug with internal phase shifter, nor a phase shifter with an on/off switch.	Transpose two phase leads on the output terminal of the starter.

**NOTICE:**

Do not reverse the phase sequence while the pump is running. Temporarily incorrect rotation can occur, resulting in damage to motor electronics and rotating parts.

The pump should start. If it does not, then contact a certified electrician to check the mains and the junctions.

# Operation

## Precautions

Before taking the unit into operation, check the following:

- All recommended safety devices are installed.
- The cable and cable entry have not been damaged.
- All debris and waste material has been removed.

---

**NOTICE:**

Never operate the pump with the discharge line blocked, or the discharge valve closed.

---



---

**WARNING: Crush Hazard**

Risk of automatic restart.

---

## Distance to wet areas



---

**WARNING: Electrical Hazard**

Risk of electrical shock or burn. You must connect an additional ground- (earth-) fault protection device to the grounded (earthed) connectors if persons are likely to come into contact with liquids that are also in contact with the pump or pumped liquid.

---



---

**CAUTION: Electrical Hazard**

Risk of electrical shock or burn. The equipment manufacturer has not evaluated this unit for use in swimming pools. If used in connection with swimming pools then special safety regulations apply.

---

## Noise level

---

**NOTICE:**

The sound power level of the product is lower than 70 dB(A). However, in some installations the resulting sound pressure level may exceed 70 dB(A) at certain operating points on the performance curve. Make sure that you understand the noise level requirements in the environment where the product is installed. Failure to do so may result in hearing loss or violation of local laws.

---

## Start the pump



---

**CAUTION: Crush Hazard**

The starting jerk can be powerful. Make sure nobody is close to the unit when it is started.

---

---

**NOTICE:**

Make sure that the rotation of the impeller is correct. For more information, see Check the impeller rotation.

---

1. Inspect the pump. Check that there is no physical damage to the pump or cables.
2. Check the oil level in the oil housing.

- 
3. Remove the fuses or open the circuit breaker, and check that the impeller can be rotated freely.



---

**WARNING: Crush Hazard**

Never put your hand into the pump housing.

---

4. Check that the monitoring equipment (if any) works.
5. Check that the impeller rotation is correct.
6. Start the pump.

## Clean the pump

The pump must be cleaned if it has been running in very dirty water. If clay, cement or other similar dirt is left in the pump it may clog the impeller and seal, preventing the pump from working.

Let the pump run for a while in clean water, or flush it through the discharge connection.

# Maintenance

## Precautions

Before starting work, make sure that the safety instructions in the chapter *Introduction and Safety* on page 3 have been read and understood.




---

### **DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

---




---

### **WARNING: Biological Hazard**

Infection risk. Rinse the unit thoroughly with clean water before working on it.

---




---

### **CAUTION: Crush Hazard**

Make sure that the unit cannot roll or fall over and injure people or damage property.

---

Make sure that you follow these requirements:

- Check the explosion risk before you weld or use electrical hand tools.
- Allow all system and pump components to cool before you handle them.
- Make sure that the product and its components have been thoroughly cleaned.
- Make sure that the work area is well-ventilated before you open any vent or drain valves, remove any plugs, or disassemble the unit.
- Do not open any vent or drain valves or remove any plugs while the system is pressurized. Make sure that the pump is isolated from the system and that pressure is relieved before you disassemble the pump, remove plugs, or disconnect piping.

### **Ground continuity verification**

A ground (earth) continuity test must always be performed after service.

### **Maintenance guidelines**

During the maintenance and before reassembly, always remember to perform these tasks:

- Clean all parts thoroughly, particularly O-ring grooves.
- Change all O-rings, gaskets, and seal washers.
- Lubricate all springs, screws, O-rings with grease.

During the reassembly, always make sure that existing index markings are in line.

The reassembled drive unit must always be insulation-tested and the reassembled pump must always be test-run before normal operation.



## Torque values

All screws and nuts must be lubricated to achieve correct tightening torque. Screws that are screwed into stainless steel must have the threads coated with suitable lubricants to prevent seizing.

If there is a question regarding the tightening torques, please contact the local sales and service representative.

### Screws and nuts

Table 3: Stainless steel, A2 and A4, torque Nm (ft-lbs)

Property class	M4	M5	M6	M8	M10	M12	M16	M20	M24	M30
50	1.0 (0.74)	2.0 (1.5)	3.0 (2.2)	8.0 (5.9)	15 (11)	27 (20)	65 (48)	127 (93.7)	220 (162)	434 (320)
70, 80	2.7 (2)	5.4 (4)	9.0 (6.6)	22 (16)	44 (32)	76 (56)	187 (138)	364 (268)	629 (464)	1240 (915)
100	4.1 (3)	8.1 (6)	14 (10)	34 (25)	66 (49)	115 (84.8)	248 (183)	481 (355)	—	—

Table 4: Steel, torque Nm (ft-lbs)

Property class	M4	M5	M6	M8	M10	M12	M16	M20	M24	M30
8.8	2.9 (2.1)	5.7 (4.2)	9.8 (7.2)	24 (18)	47 (35)	81(60)	194 (143)	385 (285)	665 (490)	1310 (966.2)
10.9	4.0 (2.9)	8.1 (6)	14 (10)	33 (24)	65 (48)	114 (84)	277 (204)	541 (399)	935 (689)	1840 (1357)
12.9	4.9 (3.6)	9.7 (7.2)	17 (13)	40 (30)	79 (58)	136 (100)	333 (245)	649 (480)	1120 (825.1)	2210 (1630)

### Hexagon screws with countersunk heads

For hexagon socket head screws with countersunk head, maximum torque for all property classes must be 80% of the values for property class 8.8 above.

## Service

Regular inspection and service of the pump ensures more reliable operation.

Type of service	Purpose	Inspection interval
Inspection	To prevent operational interruptions and machine breakdown. Measures to secure performance and pump efficiency are defined and decided for each individual application. It can include such things as impeller trimming, wear part control and replacement, control of zinc-anodes and control of the stator.	Twice a year
Major overhaul	To secure a long operating lifetime for the product. It includes replacement of key components and the measures taken during an inspection.	Every year, under normal operating conditions

**NOTICE:**

Shorter intervals may be required when the operating conditions are extreme, for example with very abrasive or corrosive applications or when the liquid temperatures exceed 40°C (104°F).

**Inspection**

Regular inspection and service of the pump ensures more reliable operation.

<b>Service item</b>	<b>Action</b>
Visible parts on the pump and installation	<ol style="list-style-type: none"> <li>1. Check that all screws, bolts, and nuts are properly tightened.</li> <li>2. Check the condition of the pump casing, strainer, cover, lifting handles, eye bolts, ropes, chains, and wires.</li> <li>3. Check for worn or damaged parts.</li> <li>4. Adjust and/or replace if necessary.</li> </ol>
Pipes, valves, and other peripheral equipment	<ol style="list-style-type: none"> <li>1. Check for worn or damaged parts.</li> <li>2. Adjust and/or replace if necessary.</li> </ol>
Impeller	<ol style="list-style-type: none"> <li>1. Check for worn or damaged parts.</li> <li>2. Adjust and/or replace if necessary.</li> </ol> <p>Wear on the impeller or surrounding parts necessitates fine adjustments of the impeller or replacement of worn parts.</p>
Oil	<p>Check the oil:</p> <ol style="list-style-type: none"> <li>1. Take an oil sample.</li> <li>2. If the oil contains particles, then replace the mechanical seal. Contact an authorized service shop.</li> </ol> <p>Make sure that the volume is filled to the correct level. A smaller amount of water is not harmful for the mechanical seal.</p>
Cable entry	<ol style="list-style-type: none"> <li>1. Check that the following requirements are met: <ul style="list-style-type: none"> <li>- The cable clamps must be properly tightened.</li> <li>- Standard pump version: The cable entry must be firmly tightened into its bottom-most position.</li> <li>- The seal sleeve and the washers must conform to the outside diameter of the cables.</li> </ul> </li> <li>2. Cut off a piece of the cable so that the seal sleeve closes around a new position on the cable.</li> <li>3. Replace the seal sleeve, if necessary.</li> </ol>
Inspection volume <sup>1</sup>	<ol style="list-style-type: none"> <li>1. Check that the inspection screw is properly tightened.</li> <li>2. Remove the inspection screw.</li> <li>3. Drain all liquid, if any.</li> <li>4. If there is oil in the inspection volume, then empty the oil and check again after one week. If there is oil in the inspection volume again, then replace the mechanical seal. Contact an authorized service shop.</li> <li>5. If there is water in the inspection volume, then check that the inspection screw O-ring is not damaged.</li> </ol>

<sup>1</sup> Regardless of individual applications, the inspection volume should not be inspected less frequently than the intervals for normal applications and operating conditions at media (liquid) temperatures <40°C (104°F).

Service item	Action
Cable	<ol style="list-style-type: none"> <li>1. If the outer jacket is damaged, replace the cable.</li> <li>2. Check that the cables do not have any sharp bends and are not pinched.</li> </ol>
Cooling system	If the flow through the system has been partly restricted, then rinse and clean.
Level sensors or other sensor equipment	<ol style="list-style-type: none"> <li>1. Check the functionality.</li> <li>2. Repair or replace any damaged equipment.</li> <li>3. Clean and adjust the equipment.</li> </ol>
Starter equipment	<ol style="list-style-type: none"> <li>1. Check the condition and functionality.</li> <li>2. Contact an electrician, if necessary.</li> </ol>
Insulation resistance in the stator	<ol style="list-style-type: none"> <li>1. Check the insulation between: <ul style="list-style-type: none"> <li>- Phase-phase on the stator</li> <li>- Phase-ground (earth)</li> </ul> The insulation should be &gt; 1 megaohm. Use a 1000-VDC megger to test the insulation. </li> <li>2. If the resulting value is &lt; 1 megaohm, then contact an authorized service shop.</li> </ol>

## Major overhaul

For a major overhaul, do the following in addition to the tasks listed under Inspection.

Service item	Action
Support and main bearing	Replace the bearings with new bearings.
Mechanical seal	Replace with new seal units.

## Change the oil

A paraffin oil with viscosity close to ISO VG32 is recommended. The pump is delivered from the factory with this type of oil. Examples of suitable oil types are the following:

- Statoil MedicWay 32™
- BP Enerpar M 004™
- Shell Ondina 927™
- Shell Ondina X430™

In applications where poisonous properties are of less concern, a mineral oil with viscosity up to ISO VG32 can be used.

## Empty the oil

1. Lay the pump on its side.  
Lock the pump with supports to prevent it from rolling over.
2. Remove the oil plug.
3. Remove the oil screw.

There are two oil screws. Either screw can be used for drainage, but it is easier to drain the oil if both oil screws are removed.



### **CAUTION: Compressed Gas Hazard**

Air inside the chamber may cause parts or liquid to be propelled with force. Be careful when opening. Hold a rag over the plug to prevent liquid from spraying out.

4. Fit the oil drainage tube (optional).  
The tube is included with the pump at delivery.
5. Turn the pump so that the oil hole faces downwards and let the oil run out into a container.



### Fill with oil

1. Replace the oil screw O-ring.
2. Put one of the oil screws back and tighten it.
3. Put the corresponding oil plug back.
4. Turn the pump so that the oil hole faces upwards and fill with new oil.  
Quantity: 5 L (5.3 qt)



5. Put the oil screw back and tighten it.  
Tightening torque: 10–20 Nm (7.4–15 ft-lbs)
6. Put the oil plug back.

## Replace the impeller

Before you replace the impeller, drain the oil in the oil housing. See applicable steps in [Change the oil](#) on page 33.

### Remove the impeller, alternative 1



#### **CAUTION: Cutting Hazard**

Worn parts can have sharp edges. Wear protective clothing.

**Table 5: Applicability**

Product code	Pressure class	Open or closed impeller
8107.030	L	Open
8107.590	N, H	Open

1. Lay the pump on its side or turn it upside down.
2. Remove the strainer:
  - a) Remove the nuts.
  - b) Remove the strainer.
3. Remove the suction cover:
  - a) Remove the nuts.
  - b) Remove the washers.
  - c) Remove the suction cover.



- d) Remove the O-ring.
4. Remove the impeller:
  - a) Remove the impeller nut.  
For 8107.030, the fastener is a screw.
  - b) Remove the washer.
  - c) Pull off the impeller.  
Use an impeller puller or pry off carefully with two strong screwdrivers or bars.



## Remove the impeller, alternative 2



### **CAUTION: Cutting Hazard**


Worn parts can have sharp edges. Wear protective clothing.

**Table 6: Applicability**

Product code	Pressure class	Open or closed impeller
8107.300	H	Closed
8107.011	H	Closed


The illustrations are generic.

1. Remove the strainer.




WS001334B

2. Remove the suction cover.
3. Remove the O-ring.
4. Loosen the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Remove the impeller screw and the washer.



WS001332A

5. Remove the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Turn the adjustment screw counterclockwise until the impeller breaks free from the shaft.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.



WS001335B

c) Pull off the impeller.

### Remove the impeller, alternative 3




#### **CAUTION: Cutting Hazard**

Worn parts can have sharp edges. Wear protective clothing.

Table 7: Applicability

Product code	Pressure class	Open or closed impeller
8107.011	SH	Closed

1. Remove the strainer.



WS001349B


2. Remove the suction cover.

3. Remove the O-ring.


4. Loosen the impeller:

a) Lock the impeller to prevent rotation.

- Use pliers, a screwdriver, or similar.
- b) Remove the impeller screw and the washer.




- 5. Remove the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Turn the adjustment screw counterclockwise until the impeller breaks free from the shaft.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.




- c) Pull off the impeller.
- 6. Remove the lower diffuser.





7. Remove the inner diffuser.
8. Remove the upper diffuser.
9. Remove the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Turn the adjustment screw counterclockwise until the impeller breaks free from the shaft.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.



- c) Pull off the impeller.

## Remove the impeller, alternative 4



### **CAUTION: Cutting Hazard**


Worn parts can have sharp edges. Wear protective clothing.

**Table 8: Applicability**

Product code	Pressure class	Open or closed impeller
8107.011	N, H	Open
8107.300	H	Open


The illustrations are generic.

1. Remove the strainer.




WS001334B

2. Loosen the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Remove the impeller screw and the washer.



WS001332A

3. Remove the impeller:
  - a) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - b) Turn the adjustment screw counterclockwise until the impeller breaks free from the shaft.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.
  - c) Remove the suction cover.
  - d) Remove the O-ring.
  - e) Pull off the impeller.



WS001335B

## Install the impeller, alternative 1

Table 9: Applicability

Product code	Pressure class	Open or closed impeller
8107.030	L	Open
8107.590	N, H	Open


### 1. Prepare the shaft:

- a) Polish off any flaws with a fine emery cloth.  
The end of the shaft must be clean and free from burrs.
- b) Clean and grease all sealing surfaces and O-rings.  
Do not use molybdenum disulphide ( $\text{MoS}_2$ ).
- c) Grease the end of the shaft and the impeller hub.
- d) Insert the key in the keyway of the shaft.
- e) Fit an appropriate number of adjusting washers on the shaft.



WS001820A

2. Check that the driving pin on the outer seal aligns with the key.
3. Without turning the shaft in relation to the driving ring, push the impeller carefully so that the pin fits into the impeller keyway.



4. Fit the washer and the nut. For 8107.030, the fastener is a screw.
5. Tighten the impeller nut. For 8107.030, the fastener is a screw.

Product code	Tightening torque, Nm (ft-lb)
8107.030	76 (57) Tighten a further 1/8 turn, 45° after tightening to the correct torque.
8107.590	200 (150)

6. Secure with washer.
7. Check that the impeller can rotate freely.

## Install the impeller, alternative 2


Table 10: Applicability

Product code	Pressure class	Open or closed impeller
8107.011	H	Closed
8107.300	H	Closed

1. Prepare the shaft:
  - a) Polish off any flaws with a fine emery cloth.  
The end of the shaft must be clean and free from burrs.
  - b) Coat the inner conic, the outer cylindrical surfaces, and the thread of the conical sleeve with a thin layer of grease.  
The proper lubrication is grease for bearings, for example Exxon Mobil Unirex N3, Mobil Mobilith SHC 220 or equivalent.


**NOTICE:**

Surplus grease can cause the impeller to become loose. Remove surplus grease from conical and/or cylindrical surfaces of shafts and/or sleeves.




WS006895A

2. Align the edge of the adjustment screw with the edge of the conical sleeve so that they are flush.



WS001759A


3. Grease the threads of the impeller screw and the washer.  
The proper lubrication of the screw and washer is lubricating grease for assembly of bolts etc., for example, Kluber ALTEMP Q NB 50 or equivalent.
4. Check that the impeller screw is clean and easy to screw into the shaft end.  
This is to prevent the shaft from rotating with the impeller screw.
5. Assemble the conical sleeve in the impeller.  
Make sure that the conical sleeve bottoms in the impeller.




WS001325B

6. Assemble the impeller with the conical sleeve onto the shaft.  
Make sure that the conical sleeve bottoms in the impeller.

7. Mount the suction cover with its O-ring and tighten.  
Tightening torque: 76 Nm (57 ft-lb)




8. Turn the adjustment screw clockwise until the impeller makes contact with the suction cover. Tighten a further 1/8 turn, 45°. This will ensure the correct clearance between the impeller and the suction cover in the next step.  
Use a 12 mm hexagon bit adapter (Allen socket).



9. Fasten the impeller:
  - a) Place the washer on the impeller screw.
  - b) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - c) Tighten the impeller screw.  
Tightening torque: 76 Nm (57 ft-lb)
  - d) Tighten a further 1/8 turn, 45°.

The screw will be loaded to its yield point and the load capacity of the joint will be higher.


- e) Check that the impeller can rotate freely.



WS001328A

10. Mount the strainer and the nuts.

Tightening torque: 76 Nm (57 ft-lb)



WS001331A

### Install the impeller, alternative 3

Table 11: Applicability

Product code	Pressure class	Open or closed impeller
8107.011	SH	Closed

1. Prepare the shaft:

- a) Polish off any flaws with a fine emery cloth.


The end of the shaft must be clean and free from burrs.

- b) Coat the inner conic, the outer cylindrical surfaces, and the thread of the conical sleeve with a thin layer of grease.

The proper lubrication is grease for bearings, for example Exxon Mobil Unirex N3, Mobil Mobilith SHC 220 or equivalent.


**NOTICE:**

Surplus grease can cause the impeller to become loose. Remove surplus grease from conical and/or cylindrical surfaces of shafts and/or sleeves.



WS006895A

- 2. Align the edge of the upper adjustment screw with the edge of the upper conical sleeve so that they are flush.



WS001759A


- 3. Grease the threads of the impeller screw and the washer.

The proper lubrication of the screw and washer is lubricating grease for assembly of bolts etc., for example, Kluber ALTEMP Q NB 50 or equivalent.

- 4. Check that the impeller screw is clean and easy to screw into the shaft end.


This is to prevent the shaft from rotating with the impeller screw.






WS001344A

5. Assemble the upper conical sleeve and the upper impeller onto the shaft.
6. Mount the diffuser parts and tighten.




WS001338B

7. Mount the suction cover with its O-ring and tighten.  
Tightening torque: 76 Nm (57 ft-lb)




WS001342B

8. Turn the adjustment screw clockwise until the impeller makes contact with the suction cover.  
This will ensure the correct clearance between the impeller and the suction cover in the next step.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.




9. Remove the suction cover.




10. Remove the O-ring.


11. Align the edge of the lower adjustment screw with the edge of the lower conical sleeve so that they are flush.




12. Assemble the lower conical sleeve and the lower impeller onto the shaft end of the upper impeller.



13. Mount the suction cover with its O-ring and tighten.  
Tightening torque: 76 Nm (57 ft-lb)




14. Turn the lower adjustment screw clockwise until the lower impeller makes contact with the suction cover. Tighten a further 1/6 turn, 60°.  
This will ensure the correct clearance between the lower impeller and the suction cover in the next step.  
Use a 12 mm hexagon bit adapter (Allen socket) with a 100 mm (4 in) extension.



WS001352A

15. Fasten the impeller:

- a) Place the washer on the impeller screw.
- b) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
- c) Tighten the impeller screw.  
Tightening torque: 76 Nm (57 ft-lb)
- d) Tighten a further 1/8 turn, 45°.  
The screw will be loaded to its yield point and the load capacity of the joint will be higher.
- e) Check that both the upper and lower impeller can rotate easily.




WS001339A

16. Check that the impeller can rotate freely.

If not, then the adjustment screw and the conical sleeve have not been aligned, and the shaft may have been displaced relative to the main bearing.

17. Mount the strainer and the nuts.

Tightening torque: 76 Nm (57 ft-lb)



## Install the impeller, alternative 4

Table 12: Applicability

Product code	Pressure class	Open or closed impeller
8107.011	N, H	Open
8107.300	H	Open

### 1. Prepare the shaft:

- a) Polish off any flaws with a fine emery cloth.


The end of the shaft must be clean and free from burrs.

- b) Coat the inner conic, the outer cylindrical surfaces, and the thread of the conical sleeve with a thin layer of grease.


The proper lubrication is grease for bearings, for example Exxon Mobil Unirex N3, Mobil Mobilith SHC 220 or equivalent.

### NOTICE:

Surplus grease can cause the impeller to become loose. Remove surplus grease from conical and/or cylindrical surfaces of shafts and/or sleeves.




2. Align the edge of the adjustment screw with the edge of the conical sleeve so that they are flush.




WS001759A

3. Grease the threads of the impeller screw and the washer.  
The proper lubrication of the screw and washer is lubricating grease for assembly of bolts etc., for example, Kluber ALTEMP Q NB 50 or equivalent.
4. Check that the impeller screw is clean and easy to screw into the shaft end.  
This is to prevent the shaft from rotating with the impeller screw.
5. Assemble the conical sleeve in the impeller.  
Make sure that the conical sleeve bottoms in the impeller.



WS001325B

6. Assemble the impeller with the conical sleeve onto the shaft.
7. Press the impeller against the seal housing cover. Turn the adjustment screw clockwise until the clearance between the impeller and the seal housing cover is 0.5–0.7 mm (0.02–0.03 in).
8. Fasten the impeller:
  - a) Place the washer on the impeller screw.
  - b) Lock the impeller to prevent rotation.  
Use pliers, a screwdriver, or similar.
  - c) Tighten the impeller screw.  
Tightening torque: 76 Nm (57 ft-lb)
  - d) Tighten a further 1/8 turn, 45°.  
The screw will be loaded to its yield point and the load capacity of the joint will be higher.



## Adjust the impeller

Table 13: Applicability

Product code	Pressure class	Open or closed impeller
8107.011	N, H	Open
8107.030	L	Open
8107.300	H	Open
8107.590	N, H	Open

In order for the pump to perform at maximum capacity, the impeller must be adjusted regularly. The impeller clearance should be minimal when the impeller is tightened. Use the adjusting washers to adjust the clearance.


Pumps that are equipped with polyurethane covering are extremely resistant to wear. If the impeller does not rotate freely, then the friction generates a lot of heat. This can result in deformed wear parts, a stuck impeller, or damage to the pump. The impeller clearance should be 0.2–0.3 mm (0.008–0.012 in) when the impeller is tightened.



1. Check that the impeller can rotate freely.
2. Turn the adjusting nuts down to the bottom of the studs.  
N: Check that the spacers are seated on the studs.



3. Fit the O-ring.  
Fit the washers also.
4. Press the suction cover against the impeller.
5. Tighten the adjusting nuts so that they lie flush against the suction cover.



6. Back off all adjusting nuts another half turn (counter-clockwise).
7. Place washers and nuts on the studs. Tighten the nuts evenly all around.
8. Check that the impeller can rotate freely.  
The impeller clearance should be 0.2–0.3 mm (0.008–0.012 in) when the impeller is tightened.
9. Lock the nuts with tab washers.
10. Install the strainer.

## Replace the diffuser

1. Remove the diffuser:
  - a) Remove the impeller, see previous instructions.
  - b) Remove the screws and washers.



- c) Remove the diffuser.





2. Install the diffuser:
  - a) Mount the diffuser.
  - b) Fasten the diffuser with the screws and washers.  
Tightening torque: 160–200 Nm (120–150 ft-lb)

# Troubleshooting

## Introduction




---

### **DANGER: Electrical Hazard**

Troubleshooting a live control panel exposes personnel to hazardous voltages. Electrical troubleshooting must be done by a qualified electrician.

---

Follow these guidelines when troubleshooting:

- Disconnect and lock out the power supply except when conducting checks that require voltage.
- Make sure that no one is near the unit when the power supply is reconnected.
- When troubleshooting electrical equipment, use the following:
  - Universal instrument multimeter
  - Test lamp (continuity tester)
  - Wiring diagram

## The pump does not start




---

### **DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

---

### **NOTICE:**

Do NOT override the motor protection repeatedly if it has tripped. Doing so may result in equipment damage.



---

<b>Cause</b>	<b>Remedy</b>
An alarm signal has been triggered on the control panel.	Check that: <ul style="list-style-type: none"> <li>• The impeller rotates freely.</li> <li>• The sensor indicators do not indicate an alarm.</li> <li>• The overload protection is not tripped.</li> </ul> If the problem still persists: Contact the local Grindex service shop.
The pump does not start automatically, but can be started manually.	Check that: <ul style="list-style-type: none"> <li>• The start level regulator is functioning. Clean or replace if necessary.</li> <li>• All connections are intact.</li> <li>• The relay and contactor coils are intact.</li> <li>• The control switch (Man/Auto) makes contact in both positions.</li> </ul> Check the control circuit and functions.

<b>Cause</b>	<b>Remedy</b>
The installation is not receiving voltage.	Check that: <ul style="list-style-type: none"><li>• The main power switch is on.</li><li>• There is control voltage to the start equipment.</li><li>• The fuses are intact.</li><li>• There is voltage in all phases of the supply line.</li><li>• All fuses have power and that they are securely fastened to the fuse holders.</li><li>• The overload protection is not tripped.</li><li>• The motor cable is not damaged.</li></ul>
The impeller is stuck.	Clean: <ul style="list-style-type: none"><li>• The impeller</li><li>• The sump in order to prevent the impeller from clogging again.</li></ul>

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

## The pump does not start, for pumps with SMART™

Cause	Remedy
<p>The phase sequence may be incorrect.</p>	<ol style="list-style-type: none"> <li>1. Pull out the plug.</li> <li>2. Do one of the following:                             <ul style="list-style-type: none"> <li>- Shift two phases by turning two contact pins with a screwdriver.</li> </ul> </li> </ol> <hr/> <p><b>NOTICE:</b> Do not take the plug apart.</p> <hr/>  <p style="text-align: right; font-size: small;">WS002614A</p> <p><b>Figure 9: CEE plug</b></p> <ul style="list-style-type: none"> <li>- Turn the knob to the opposite position 1, with 8 seconds delay.</li> </ul> <hr/> <p><b>NOTICE:</b> Do not reverse the phase sequence while the motor is running. Doing so may cause incorrect rotation resulting in damages to the motor electronics and the rotating parts. Respect the 8 seconds delay.</p> <hr/>  <p style="text-align: center; font-size: small;">WS002616A                      WS002615A</p> <p><b>Figure 10: Phase shifter On/Off switch</b></p> <ul style="list-style-type: none"> <li>- If no glove or phase shifter is used, then shift two phase conductors in the cabinet.</li> </ul>

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

## The pump does not stop when a level sensor is used



**DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

Cause	Remedy
The pump is unable to empty the sump to the stop level.	Check that: <ul style="list-style-type: none"> <li>• There are no leaks from the piping and/or discharge connection.</li> <li>• The impeller is not clogged.</li> <li>• The non-return valve(s) are functioning properly.</li> <li>• The pump has adequate capacity. For information: Contact the local Grindex service shop.</li> </ul>
There is a malfunction in the level-sensing equipment.	<ul style="list-style-type: none"> <li>• Clean the level regulators.</li> <li>• Check the functioning of the level regulators.</li> <li>• Check the contactor and the control circuit.</li> <li>• Replace all defective items.</li> </ul>
The stop level is set too low.	Raise the stop level.

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

## The pump starts-stops-starts in rapid sequence

Cause	Remedy
The pump starts due to back-flow which fills the sump to the start level again.	Check that: <ul style="list-style-type: none"> <li>• The distance between the start and stop levels is sufficient.</li> <li>• The non-return valve(s) work(s) properly.</li> <li>• The length of the discharge pipe between the pump and the first non-return valve is sufficiently short.</li> </ul>
The self-holding function of the contactor malfunctions.	Check: <ul style="list-style-type: none"> <li>• The contactor connections.</li> <li>• The voltage in the control circuit in relation to the rated voltages on the coil.</li> <li>• The functioning of the stop-level regulator.</li> <li>• Whether the voltage drop in the line at the starting surge causes the contactor's self-holding malfunction.</li> </ul>

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

## The pump runs but the motor protection trips




### **DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

### **NOTICE:**

Do NOT override the motor protection repeatedly if it has tripped. Doing so may result in equipment damage.

Cause	Remedy
The motor protection is set too low.	Set the motor protection according to the data plate and if applicable the cable chart.
The impeller is difficult to rotate by hand.	<ul style="list-style-type: none"> <li>• Clean the impeller.</li> <li>• Clean out the sump.</li> <li>• Check that the impeller is properly trimmed.</li> </ul>
The drive unit is not receiving full voltage on all three phases.	<ul style="list-style-type: none"> <li>• Check the fuses. Replace fuses that have tripped.</li> <li>• If the fuses are intact, then notify a certified electrician.</li> </ul>
The phase currents vary, or they are too high.	Contact the local Grindex service shop.
The insulation between the phases and ground in the stator is defective.	<ol style="list-style-type: none"> <li>1. Use an insulation tester. With a 1000 V DC megger, check that the insulation between the phases and between any phase and ground is &gt; 5 megaohms.</li> <li>2. If the insulation is less, then do the following: Contact the local Grindex service shop.</li> </ol>
The density of the pumped fluid is too high.	<p>Make sure that the maximum density is 1100 kg/m<sup>3</sup> (9.2 lb/US gal)</p> <ul style="list-style-type: none"> <li>• Change to a more suitable pump</li> <li>• Contact the local Grindex service shop.</li> </ul>
The ambient temperature exceeds the maximum ambient temperature.	The pump must not be used for such an application.
There is a malfunction in the overload protection.	Replace the overload protection.
The SMART™ motor protection may need to be reset.	<p>Try one of the following:</p> <ul style="list-style-type: none"> <li>• Reset the SMART™ motor protection by pulling and reinserting the power plug.</li> <li>• Or, disconnect and reconnect the power.</li> </ul> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p><b>WARNING: Crush Hazard</b> Risk of automatic restart.</p> </div> </div>

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

## The pump delivers too little or no water



### **DANGER: Crush Hazard**

Moving parts can entangle or crush. Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

**NOTICE:**

Do NOT override the motor protection repeatedly if it has tripped. Doing so may result in equipment damage.

Cause	Remedy
The impeller rotates in the wrong direction.	<ul style="list-style-type: none"> <li>• If it is a 3-phase pump without SMART™, then transpose two phase leads.</li> <li>• If it is a 3-phase pump with SMART™, then correct the internal wiring.</li> <li>• If it is a 1-phase pump, then do the following: Contact the local Grindex service shop.</li> </ul>
One or more of the valves are set in the wrong positions.	<ul style="list-style-type: none"> <li>• Reset the valves that are set in the wrong position.</li> <li>• Replace the valves, if necessary.</li> <li>• Check that all valves are correctly installed according to media flow.</li> <li>• Check that all valves open correctly.</li> </ul>
The impeller is difficult to rotate by hand.	<ul style="list-style-type: none"> <li>• Clean the impeller.</li> <li>• Clean out the sump.</li> <li>• Check that the impeller is properly trimmed.</li> </ul>
The pipes are obstructed.	To ensure a free flow, clean out the pipes.
The pipes and joints leak.	Find the leaks and seal them.
There are signs of wear on the impeller, pump, and casing.	Replace the worn parts.
The liquid level is too low.	<ul style="list-style-type: none"> <li>• Check that the level sensor is set correctly.</li> <li>• Depending on the installation type, add a means for priming the pump, such as a foot valve.</li> </ul>

If the problem persists, contact the local Grindex service shop. Always state the product number and the serial number of your pump when you contact Grindex, see [Product Description](#) on page 9.

# Technical Reference

## Application limits

Data	Description
Media (liquid) temperature	Maximum temperature 40°C (104°F)
pH of the pumped media (liquid)	6–13
Media (liquid) density	Maximum density: 1100 kg/m <sup>3</sup> (9.2 lb. per US gal.)
Depth of immersion	20 m (65 ft.)
Other	For specific weight, current, voltage, power rating, and speed of the pump, see the data plate on the pump. For starting current, see <a href="#">Motor data</a> on page 62. For other applications, contact the nearest Grindex representative for information.

## Motor data

Feature	Description
Motor type	Squirrel-cage induction motor
Frequency	Standard version: 50 or 60 Hz MSHA version: 60 Hz
Supply	3-phase
Starting method	Direct on-line Star-delta
Maximum starts per hour	30 evenly spaced starts per hour
Code compliance	IEC 60034-1
Voltage variation without overheating	±10%, provided that it does not run continuously at full load
Voltage imbalance tolerance	2%
Maximum frequency variation (for pumps with SMART™)	±3 Hz
Stator insulation class	H (180°C [360°F])

## Specific motor data: Version code .011/.030/.300



**8107.011, 3-phase, 50 Hz, N, H**

Motor type:

- 2,940 rpm
- 37 kW (50 hp)

<b>Voltage, V</b>	<b>Connection</b>	<b>Rated current, A</b>	<b>Starting current, A</b>
220	D	117	700
230	D	112	740
380	Y	67	405
380	D	67	405
400	Y	65	430
400	D	65	430
415	D	62	350
440	D	59	375
500	D	51	271
525	D	49	296
550	D	47	310
660	Y	39	231
690	Y	37	246
1000	Y	26	184

**8107.300, 3-phase, 50 Hz, H**

Motor type:

- 2,910 rpm
- 25 kW (34 hp)

<b>Voltage, V</b>	<b>Connection</b>	<b>Rated current, A</b>	<b>Starting current, A</b>
220	D	79	460
230	D	76	485
380	Y	46	265
380	D	46	258
400	Y	44	280
400	D	43	269
415	D	42	286
440	D	41	305
500	D	35	227
525	D	33	198
550	D	32	209
660	Y	26	150
690	Y	25	158
1000	Y	18	128

**8107.030, 3-phase, 50 Hz, L**

Motor type:

- 1,465 rpm
- 30 kW (40 hp)

<b>Voltage, V</b>	<b>Connection</b>	<b>Rated current, A</b>	<b>Starting current, A</b>
220	D	108	895
230	D	110	945
380	Y	62	515
380	D	61	485
400	Y	64	550
400	D	61	520
415	D	54	415
440	D	54	450
500	D	45	335
525	D	44	355
550	D	45	375
660	Y	35	281
690	Y	35	297

**8107.011, 3-phase, 60 Hz, N, H**

Motor type:

- 3,540 rpm
- 43 kW (58 hp)

<b>Voltage, V</b>	<b>Connection</b>	<b>Rated current, A</b>	<b>Starting current, A</b>
200	D	152	725
208	D	144	760
220	D	136	810
220	D//	134	710
230	D	133	895
230	D//	127	750
380	Y	78	465
380	Y//	77	410
400	Y	76	520
400	Y//	73	435
440	DSER	67	355
440	D	68	405
460	DSER	64	375
460	D	65	480
480	D	65	470
575	D	52	249

Voltage, V	Connection	Rated current, A	Starting current, A
600	D	50	284

**8107.300, 3-phase, 60 Hz, H**

Motor type:

- 3,510 rpm
- 29 kW (39 hp)

Voltage, V	Connection	Rated current, A	Starting current, A
220	D//	91	555
230	D//	87	585
380	Y//	53	320
400	Y//	50	340
440	DSER	46	277
440	D	46	260
460	DSER	43	292
460	D	44	274
480	D	42	287
575	D	35	227
600	D	33	238

**8107.030, 3-phase, 60 Hz, L**

Motor type:

- 1,760 rpm
- 37 kW (50 hp)

Voltage, V	Connection	Rated current, A	Starting current, A
200	D	138	885
208	D	130	940
220	D//	123	865
230	D//	119	915
400	D	72	605
380	D	73	565
460	DSER	59	455
400	Y//	68	530
440	DSER	61	430
380	Y//	71	495
440	D	65	495
460	D	64	480
480	D	63	520
575	D	48	305
600	D	46	360

## Specific motor data: Version code .590

### 3-phase, 60 Hz

Motor type:

- 3,540 rpm
- 43 kW (58 hp)

Voltage (V)	Rated current (A)	Starting current (A)
440 D	68	405
460 D	65	480
575 D	52	249

## Dimensions and weights

### 8107.011 SH




Figure 11: 8107.011 SH. Screen opening: 12 mm (0.47 in) diameter.

Pump	Weight without motor cable, kg (lbs)
8107.011 SH	270 (595)

## 8107.011 H and 8107.300 H




Figure 12: 8107.011 H, 8107.300 H

Pump	Weight without motor cable, kg (lbs)
8107.011 H	240 (530)
8107.300 H	285 (628)

## 8107.011 N and 8107.030 L




Figure 13: 8107.011 N, 8107.030 L

Dimension A	Dimension B
6 in (152 mm) (hose)	1332 mm (52.4 in)

Dimension A	Dimension B
8 in (203 mm) (hose)	1302 mm (51.3 in)
ISO-G6, NPT 6	1227 mm (48.3 in)
ISO-G8, NPT 8	1217 mm (47.9 in)

Pump	Weight without motor cable, kg (lbs)
8107.011 N	280 (618)
8107.030 L	285 (628)

## 8107.590 H




Figure 14: 8107.590

Pump	Weight without motor cable, kg (lbs)
8107.590 H	350 (770)

## Performance curves

### Test standard

Pumps are tested in accordance with ISO 9906:2012, HI 11.6:2012.

# 8107.011 SH



Figure 15: 8107.011 SH: 50 Hz




Figure 16: 8107.011 SH: 60 Hz

# 8107.011 N, H: Open impeller




Figure 17: 8107.011 N, H: 50 Hz




Figure 18: 8107.011 N, H: 60 Hz

### 8107.300 H: Open impeller




Figure 19: 8107.300 H: 50 Hz




Figure 20: 8107.300 H: 60 Hz



# 8107.030 L





Figure 21: 8107.030 L: 50 Hz





Figure 22: 8107.030 L: 60 Hz

# 8107.590 H




Figure 23: 8107.590 H: 60 Hz





[www.grindex.com](http://www.grindex.com)

Grindex  
Gesällvägen 33  
174 07 Sundbyberg  
Sweden  
Tel: +46-8-606 66 00  
Fax: +46-8-745 53 28  
[www.grindex.com](http://www.grindex.com)

Visit our Web site for the latest version of this document  
and more information

The original instruction is in English. All non-English  
instructions are translations of the original instruction.

© 2009 Grindex