

3

MANUAL

EDILGRAPPA

**ELECTRIC CHAIN
CUTTER TC26
SPARE PARTS**

INDEX

0 SPARE PARTS AND ACCESSORIES CATALOGUE	3
0.01 ORDERING INFORMATION	3
0.02 MECHANICAL AND ELECTRICAL COMPONENTS.....	3
COMPONENTS OF ELECTRIC CHAIN CUTTER TC26	4
P/N 1.50.1946 UP TO SERIES NUMBER 183 INCLUSIVE	4
COMPONENTS OF ELECTRIC CHAIN CUTTER TC26	7
P/N 1.50.1946 FROM SERIES NUMBER 184 INCLUSIVE	7
COMPONENTS OF ELECTRIC CHAIN CUTTER TC26	11
P/N 1.50.1946 FROM SERIES NUMBER 192 INCLUSIVE	11

0 SPARE PARTS AND ACCESSORIES CATALOGUE



THE COMPANY DECLINES ALL LIABILITY FOR INJURY TO PEOPLE OR DAMAGE TO PROPERTY IF TECHNICAL ASSISTANCE IS NOT PERFORMED BY QUALIFIED AND AUTHORISED STAFF.



FOR TECHNICAL ASSISTANCE AND MAINTENANCE, CONTACT AN AUTHORISED SERVICE CENTRE OR WRITE TO cut@edilgrappa.com.

0.01 ORDERING INFORMATION

For technical assistance and spare parts, both during and after the period of warranty, quote the data indicated on the ID plates and the serial number punched on the tool body (fig. 1)




Fig.1

Orders for spare parts must be accompanied by the following information:


1. Type of equipment
2. Serial number
3. Part number, revision status and position in exploded drawing
4. Quantity
5. Revision status indicated on the back cover of the manual.

The Manufacturer can only supply the appropriate spare part if the required data is complete, since subsequent improvements may have entailed structural variations to the equipment and therefore to the spare parts.

0.02 MECHANICAL AND ELECTRICAL COMPONENTS

The following page contains an exploded diagram of the machine, complete with the part numbers, descriptions and quantities of each component.

COMPONENTS OF ELECTRIC CHAIN CUTTER TC26 P/N 1.50.1946 UP TO SERIAL NUMBER 183 INCLUSIVE



COMPONENTS OF ELECTRIC CHAIN CUTTER TC26

P/N 1.50.1946 UP TO SERIAL NUMBER 183 INCLUSIVE


Pos.	P/N	Item	Q.ty
1	1 60 207	NUT	8
2	1 60 319	WASHER	2
3	1 60 501	SCREW	1
4	1 60 718	SCREW	2
5	1.10.030	CHARGING VALVE ADJUSTMENT SCREW	1
6	1.10.031	POPPET FOR CALIBRATION VALVE	1
7	1.10.032	BODY FOR MANUAL RETURN VALVE	1
8	1.10.036	SPRING	1
9	1.10.091	SPRING	1
10	1.10.099	SPRING FOR BRUSH HOLDER	2
11	1.10.103	BRUSH HOLDER SUPPORT	2
12	1.10.1725	OIL TANK	1
13	1.10.1726	COVER FOR TANK	1
14	1.10.207	CAP	1
15	1.10.253	SPRING	1
16	1.10.4073	HEAD LOCK SCREW	1
17	1.10.4241	MANUAL VALVE LEVER	1
18	1.10.4393	MEMBRANE RETAINER	1
19	1.10.4426	SHORT FIXED BLADE	1
*20	1.10.4429	HEAD FOR CHAIN CUTTER	1
21	1.10.4482	CYLINDER	1
22	1.10.4484	LONG FIXED BLADE	1
23	1.10.4500	POLYCARBONATE INSPECTION WINDOW	1
24	1.10.4503	RUBBER PAD	1
25	1.10.4897	MOBILE BLADE	1
26	1.10.4898	LOCK PIN FOR MOBILE BLADE	1
27	1.10.4899	PIN FOR MANUAL RETURN VALVE	1
28	1.10.696	BRUSH HOLDER PLATE	2
29	1.10.811	WASHER	4
30	1.30.005	MOTOR BRUSH	2
31	1.30.015	O-RING	1
32	1.30.017	O-RING	3
33	1.30.020	PLASTIC CABLE CLAMP	1
34	1.30.021	CABLE HOLDER	1
35	1.30.034	MOTOR COVER	1
36	1.30.037	MOTOR COVER	2
37	1.30.046	O-RING	1
38	1.30.1834	O-RING	1
39	1.30.220	O-RING	1
40	1.30.276	MEMBRANE	1
41	1.30.286	RH HANDLE HALF-SHELL	1
42	1.30.287	LH HANDLE HALF-SHELL	1

Pos.	P/N	Item	Q.ty
*43	1.30.367	GASKET	1
44	1.30.386	GASKET	1
45	1.30.461	FAN	1
46	1.40.002	ANTI-DISTURBANCE FILTER	1
47	1.40.012	CABLE WITH PLUG	1
48	1.40.016	STATOR STACK	1
49	1.40.024	ROTOR	1
50	1.40.147	SWITCH	1
51	1.50.1407	GUARD ASSEMBLY	1
*52	1.50.1442	PISTON ASSEMBLY	1
53	1.50.506	CAP WITH MAGNETIC FILTER	1
54	1.50.511	PUMP ASSEMBLY	1
55	1.60.003	BEARING	1
56	1.60.012	STEEL BALL-BEARING	1
57	1.60.013	BEARING	1
58	1.60.014	OIL GUARD	1
59	1.60.068	BEARING	1
60	1.60.105	SCREW	4
61	1.60.129	SCREW	2
63	1.60.142	SCREW	2
64	1.60.143	SCREW	4
65	1.60.144	SCREW	2
66	1.60.147	SCREW	4
67	1.60.151	SCREW	4
68	1.60.205	BRASS BLIND NUT	1
69	1.60.302	WASHER	1
70	1.60.307	COPPER WASHER	1
71	1.60.314	SPRING WASHER	4
72	1.60.322	WASHER	2
73	1.60.324	ADJUSTING RING	2
74	1.60.337	GASKET FOR MAGNETIC CAP	1
75	1.60.361	COPPER WASHER	1
76	1.60.382	TOOTHED WASHER	2
77	1.60.410	SCHNORR WASHER	4
78	1.60.817	SCREW	4
79	1.60.894	SCREW	6
80	1.60.933	SCREW	1
81	1.60.937	SCREW	2
82	1.70.006	COPPER WASHER	1
83	1.70.025	SELF-TAPPING SCREW	2
84	1.90.127	ADHESIVE ID LABEL	1

FOR MACHINES WITH SERIES NUMBER FROM 153 TO 162 INCLUSIVE:

*20	1.10.5704	HEAD FOR CHAIN CUTTER	1
*43	1.30.634	GASKET	1
*52	1.50.1616	PISTON ASSEMBLY	1

COMPONENTS OF ELECTRIC CHAIN CUTTER TC26
P/N 1.50.1946 FROM SERIAL NUMBER 184 INCLUSIVE




**COMPONENTS OF ELECTRIC CHAIN CUTTER TC26
P/N 1.50.1946 FROM SERIAL NUMBER 184 INCLUSIVE**

Pos.	P/N	Rev.	Item	Q.ty
1	1 60 501	0	SCREW	1
2	1.10.4429	8	HEAD	1
3	1.30.367	1	GASKET	1
4	1.10.091	0	SPRING	1
5	1.50.1442	0	PISTON ASSEMBLY	1
6	1.30.386	0	GASKET	1
7	1.30.1834	0	O-RING	1
8	1.10.4073	2	HEAD LOCK SCREW	1
9	1.70.006	0	COPPER WASHER	1
10	1.10.4482	6	CYLINDER	1
11	1.60.012	1	STEEL BALL-BEARING	1
12	1.60.307	0	COPPER WASHER	1
13	1.10.032	0	MANUAL RETURN VALVE BODY	1
14	1.30.015	1	O-RING	1
15	1.10.4899	0	MANUAL RETURN VALVE PIN	1
16	1.50.1924	0	MANUAL RETURN VALVE LEVER ASSEMBLY	1
17	1.30.046	2	O-RING	1
18	1.30.017	2	O-RING	3
19	1.60.068	1	BEARING	1
20	1.50.511	1	PUMP ASSEMBLY	1
21	1.10.1726	2	COVER FOR CENTRAL TANK ELEMENT	1
22	1.10.253	0	SPRING	1
23	1.10.4393	1	MEMBRANE RETAINER	1
24	1.30.276	1	MEMBRANE	1
25	1.10.1725	4	OIL TANK	1
26	1.60.337	2	BONDED SEAL WASHER	1
27	1.50.506	2	MAGNETIC CAP	1

Pos.	P/N	Rev.	Item	Q.ty
28	1.60.014	0	OIL GUARD	1
29	1.10.4484	4	LONG FIXED BLADE "A"	1
30	1.10.4426	6	SHORT FIXED BLADE "B"	1
31	1.10.6375	2	MOBILE BLADE	1
32	1.10.6374	1	MOBILE BLADE SUPPORT	1
33	1.10.4898	1	LOCK PIN FOR MOBILE BLADE	1
34	1.30.220	0	O-RING	1
35	1.10.6376	1	BLADE RETAINER	1
36	1 60 161	0	SCREW	2
37	1.10.4500	0	POLYCARBONATE INSPECTION WINDOW	1
38	1 60 718	0	SCREW	2
39	1.50.1407	3	GUARD ASSEMBLY	1
40	1.10.4499	3	SHIM FOR GUARD	2
41	1.10.4503	1	RUBBER PAD	1
42	1.60.817	1	SCREW	4
43	1.60.205	0	BRASS BLIND NUT	1
44	1.60.013	2	BEARING	1
45	200.009E	0	ROTOR ASSEMBLY WITH FAN	1
46	1.50.1912	0	CALIBRATION VALVE ASSEMBLY	1
47	1.60.937	1	SCREW	2
48	1.60.142	0	SCREW	2
49	1.60.382	0	TOOTHED WASHER	2
50	1.40.016	0	STATOR STACK	1
51	1.60.003	2	BEARING	1
52	1.60.324	1	ADJUSTING RING	2
53	1.30.034	2	MOTOR COVER	1
54	1.10.811	1	WASHER	2
55	1 60 207	0	NUT M4 - UNI 5588-65-A-6S	2
56	1.50.1936	1	BRUSH HOLDER KIT	1
57	1.30.005	0	MOTOR BRUSH	1
58	1.50.1391	0	BRUSH COVER ASSEMBLY	1
59	1.60.151	1	SELF-TAPPING SCREW	4

Pos.	P/N	Rev.	Item	Q.ty
60	1.60.314	0	SPRING WASHER	4
61	1.60.410	0	TOOTHED WASHER	4
62	1.60.105	0	SCREW	4
63	1.40.147	0	SWITCH	1
64	1.40.002	0	ANTI-DISTURBANCE FILTER	1
65	1.30.020	0	PLASTIC CABLE CLAMP	1
66	1.60.129	2	SELF-TAPPING SCREW	2
67	1.50.1387	0	HALF-SHELL ASSEMBLY WITH SCREWS	1
68	1.60.147	1	SELF-TAPPING SCREW	4
69	1.30.021	0	CABLE HOLDER	1
70	1.40.012	1	CABLE WITH PLUG	1

COMPONENTS OF ELECTRIC CHAIN CUTTER TC26
P/N 1.50.1946 FROM SERIAL NUMBER 192 INCLUSIVE



**COMPONENTS OF ELECTRIC CHAIN CUTTER TC26
P/N 1.50.1946 FROM SERIAL NUMBER 192 INCLUSIVE**

Pos.	P/N	Rev.	Item	Q.ty
1	1 60 501	0	SCREW	1
2	1.10.4429	8	HEAD	1
3	1.30.367	1	GASKET	1
4	1.10.091	0	SPRING	1
5	1.50.1442	1	PISTON ASSEMBLY	1
6	1.30.386	0	GASKET	1
7	1.30.1834	0	O-RING	1
8	1.10.4073	2	HEAD LOCK SCREW	1
9	1.70.006	0	COPPER WASHER	1
10	1.10.4482	6	CYLINDER	1
11	1.60.012	1	STEEL BALL-BEARING	1
12	1.60.307	0	COPPER WASHER	1
13	1.10.032	0	MANUAL RETURN VALVE BODY	1
14	1.30.015	1	O-RING	1
15	1.10.4899	0	MANUAL RETURN VALVE PIN	1
16	1.50.1924	0	MANUAL RETURN VALVE LEVER ASSEMBLY	1
17	1.30.046	2	O-RING	1
18	1.30.017	2	O-RING	3
19	1.60.1023	0	BEARING	1
20	1.50.1800	0	PUMP ASSEMBLY	1
21	1.10.1726	2	COVER FOR CENTRAL TANK ELEMENT	1
22	1.10.253	0	SPRING	1
23	1.10.4393	1	MEMBRANE RETAINER	1
24	1.30.276	1	MEMBRANE	1
25	1.10.1725	4	OIL TANK	1
26	1.60.337	2	BONDED SEAL WASHER	1
27	1.50.506	2	MAGNETIC CAP	1

Pos.	P/N	Rev.	Item	Q.ty
28	1.60.014	0	OIL GUARD	1
29	1.10.4484	4	LONG FIXED BLADE "A"	1
30	1.10.4426	6	SHORT FIXED BLADE "B"	1
31	1.10.6375	2	MOBILE BLADE	1
32	1.10.6374	1	MOBILE BLADE SUPPORT	1
33	1.10.4898	1	LOCK PIN FOR MOBILE BLADE	1
34	1.30.220	0	O-RING	1
35	1.10.6376	1	BLADE RETAINER	1
36	1 60 161	0	SCREW	2
37	1.10.4500	0	POLYCARBONATE INSPECTION WINDOW	1
38	1 60 718	0	SCREW	2
39	1.50.1407	3	GUARD ASSEMBLY	1
40	1.10.4499	3	SHIM FOR GUARD	2
41	1.10.4503	1	RUBBER PAD	1
42	1.60.937	1	SCREW	4
43	1.60.205	0	BRASS BLIND NUT	1
44	1.60.013	2	BEARING	1
45	200.009E	0	ROTOR ASSEMBLY WITH FAN	1
46	1.50.1912	0	CALIBRATION VALVE ASSEMBLY	1
47	1.60.937	1	SCREW	2
48	1.60.142	0	SCREW	2
49	1.60.382	0	TOOTHED WASHER	2
50	1.40.016	0	STATOR STACK	1
51	1.60.003	2	BEARING	1
52	1.60.324	1	ADJUSTING RING	2
53	1.30.034	2	MOTOR COVER	1
54	1.10.811	1	WASHER	2
55	1 60 207	0	NUT M4 - UNI 5588-65-A-6S	2
56	1.50.1936	1	BRUSH HOLDER KIT	1
57	1.30.005	0	MOTOR BRUSH	1
58	1.50.1391	0	BRUSH COVER ASSEMBLY	1
59	1.60.151	1	SELF-TAPPING SCREW	4

Pos.	P/N	Rev.	Item	Q.ty
60	1.60.314	0	SPRING WASHER	4
61	1.60.410	0	TOOTHED WASHER	4
62	1.60.105	0	SCREW	4
63	1.40.147	0	SWITCH	1
64	1.40.002	0	ANTI-DISTURBANCE FILTER	1
65	1.30.020	0	PLASTIC CABLE CLAMP	1
66	1.60.129	2	SELF-TAPPING SCREW	2
67	1.50.1387	0	HALF-SHELL ASSEMBLY WITH SCREWS	1
68	1.60.147	1	SELF-TAPPING SCREW	4
69	1.30.021	0	CABLE HOLDER	1
70	1.40.012	1	CABLE WITH PLUG	1

NOTES

EDILGRAPPA Srl

MACHINES AND EQUIPMENT FOR THE BUILDING TRADE, INDUSTRY
AND RESCUE

31030 BORSO DEL GRAPPA (TV) - ITALY - Via Callesello, 4
Tel. 0423 910122 – Fax 0423 542122

E-mail: cut@edilgrappa.com <http://www.edilgrappa.com>